

DIGITAL HANGING SCALE

Art. No.: EHS-026C

Operational Instructions:

WEIGHTING

Before weighting:

whenever possible, please allow the scale to warm up for 30 seconds after first turning the power on so that the scale will function properly and accurately.

Error messages:

EEEE: Overload

 : Low battery

Weighting procedures:

1. Press the  button to turn on the scale; and hold it for 3 seconds to turn off the scale.

When power is turned on, all display segments appear on LCD for a few seconds and finally "0" will appear on the display.

2. Select the weighting unit with [UNIT].

Press [UNIT] to select a weighting unit, eg. "Kg", "lb". Once the unit has been selected, the selected unit will be displayed to the weight value.

3. Start weighting.

a. If you do not use a container for weighting:

* Verify the reading is "0". If not, press  to display "0".

* Place objects on the weighting strap to weight.

* Lift the object from the ground until hearing the beep sound, this indicates that the weight has been locked and displayed.

Set the object down, and read the weight.

b. If you use a bag or other container for weighting:

* Place an empty container on the strap and proceed to weight it.

* Wait for the stability weighting value to be displayed and press  to display "0".

* Place the objects to be weighted in the container.

* Lift the objects from the ground until hearing the beep sound, this indicates that the weight has been locked and displayed.


Set the object down, and read the weight.

1. Only for hobby, household use, not for commercial use.
2. Cannot be used to weigh fishes for price counting.

DIGITAL HANGING SCALE

Art. No.: EHS-026C

Specification:



● Weighting procedures:

- * Just lift the object, wait to hear the beep sound, and set it down.
- * Press the "Reset" button to start again.

● Lift, wait for the Beep! And Set it down.

● Operates with 1xCR2032 battery.

Capacity

25KG	
50KG	

